













1 Inner Mesh Construction

This construction offers the superior comfort and breathability you wouldn't normally expect from a modern conference chair.

2 Smart Slide Operation

We consolidated the controls into a simple cluster under the seat, everything accessible from a natural seated position. One lever controls both recline and tension. Simply slide the lever to find your best comfort.





Function




Seat Height Adjustment

Move the lever under the seat to adjust seat height. (Up/Down Stroke: 100mm)



Ankle Tilt Reclining

The back rest and seat move in tandem to recline over the ankle line. Reclined position offers support and comfort for upper thighs. (Recline Angle: Up to 15°)



1. Smart Slide Operation Lever


2. Seat Height Adjust Lever

We consolidated the seat controls on the bottom right of the seat. This means you can operate the controls from a naturally seated position. Simply use the Smart Slide Operation Lever to adjust recline tension (high/low) and to lock back rest position. You can use the same lever to raise or lower the seat.



Handle

A convenient handle for moving the chair without putting hands directly on the back rest.



Multiple Density Cushion


The seat is molded from urethane offering three different levels of firmness. The front of the chair uses a softer urethane for thigh comfort. The rear of the seat is made of a firmer cushion for greater support.

Option




Fixed Arm

Design arms can be installed at a later time.




specifications





Awar



Ecology



